

14b. Infill balusters (optional)
 Drill a base hole 12.7mm dia. x 10mm deep midway between the two balusters on the wide outer tread. (N.B. ensure that radial distance from centre post match other balusters)
 Cut infill balusters to length and screw into underside of handrail.

