

## FIXING INSTRUCTION FOR HOOK & BAR SYSTEM

Mount steel bar & bracket assembly (either face fix as in illustration or fix on to top of loft floor) with the 2" x No. 10 Pan-head screws. Position hooks on rear edge of ladder, drill pilot holes and fix using CSK 1 1/4" no.10 screws.

In the case of Aluminium ladders, use the nuts and bolts provided if the hooks are not already attached.



Units C & D  
Ford Lane Industrial Estate  
Ford, Arundel  
West Sussex, BN18 0DF  
Tel 0845 676 0704  
Fax 0845 676 0705  
Email sales@loftcentre.co.uk  
Website www.loftcentre.co.uk

