

Concertina Type Piccolo Premium

Owners manual

Installation:

Fix backboard with at least 6 screws (No 3) 6x80 mm and plugs S8(4); (can be used for concrete only), safely at hatchbox or structure. Do use empty drills of brackets for screwing.

Adjustment of springs:

(Attention : This is only possible when concertina is closed; it is only necessary when concertina lowers by its own weight.)

Use metal stick 10 x 200 mm (No 2) stick into drill hole of the springwork of the bracket after rivet punch. Turn spring work upside and put rivet punch into drillhole behind metal stick. Turn springwork down again until rivet punch touches bracket. Make sure that metal stick is not removed before rivet punch strikes bracket. Spring is under high tension, do not overwind.

Maintenance:

Check regularly if all screws, bolts and nuts are fixed.
Please oil or grease all moving parts regularly.

Safety advice:

When opening the concertina do not open over stop as there is the danger that either the backboard or parts of the concertina might be damaged.

